






DUAL CONTROL UNIT INSTRUCTIONS

	Turns on the traffic lights; hold 2 seconds to turn them off.
	Activates / deactivates the yellow flashing mode by pressing and holding for 2 seconds.
	<p>Press with the traffic light off to start programming (+ and - to modify):</p> <ul style="list-style-type: none"> - Set one control unit as L1 and the other as L2; "PROG" to confirm; - Set the red time (L1 and L2 red); press "PROG" to confirm; - Set the time of L1 green; press "PROG" to confirm; - Set the time of L2 green; press "PROG" to confirm and exit the menu..
	<p>Press simultaneously on both control units to synchronize them manually. ATTENTION: the time settings must be identical on both control units before starting the sync.</p>
	<p>Bring the two control units together and press this button to start automatic sync. (L1 transmits "ttt" and L2 receives "rrr"). On L2 there is a confirmation animation.</p>

TRUBLESHOOTING

\bAt	followed by a value, indicates the battery voltage;
no SYn	(yellow LEDs flashing) indicates that the control unit is not synchronized;
SYn	(green LED flashing) indicates that the control unit is synchronized;
- -	(all LEDs blink) indicates that a lantern is in open circuit;
CC	(flashing of all LEDs) indicates that a lantern is in short circuit;
---	(all LEDs lit) indicates that there are no connection errors.